



PREPARING FOR YOUR LOGICOURT

Prior to installation, there will be some work that you need to do to prepare:

- Trim doors
- Remove thresholds and cove base
- Adjust goals and bleacher
- Level slab
- Abatement

After your LogiCourt is installed, you will need to add or replace:

- Door thresholds
- Perimeter cove base
- Transition ramps

The specifications for each LogiCourt panel is:

- Size: 4' x 7'
- Profile height: 2 3/4"
- Weight: 125 lbs

What you need to do when it arrives:

Your LogiCourt system will be delivered in a dry van truck. You will need to have a forklift available to unload the panels. We recommend having a two to four person crew for installation. The more people, the faster installation goes!

Please consider finding the easiest access for bringing the panels into your facility. We recommend a double door where the middle divider can come out. The ability to use a pallet jack to unload will save a lot of time and effort as well.

What Logicourt will do:

We will have a manufacturer's representative onsite for training during the installation process. We will also provide a tutorial to your facility's personnel on the proper way to install, care for, and disassemble the court.